

## Chapter 20 Single Axis Servo Control

### Servo Lab

The Servo Lab gives the student an experience with single axis motion control. Automation uses for single axis motion include indexing machines and grinders. The lab is provided to a point with students expected to expand the base program to include advanced concepts. Developing a useful HMI is a part of this lab. The student is required to provide a motion action with the capability of automatic and manual control.



Servo Motor and  
Motor Controller  
Allen-Bradley

While the servo shown is Allen-Bradley, several servos from Siemens are also in the final stages of being purchased. The cost of these servos is approximately \$1000/each. The servo communicates with the PLC via Ethernet. The goal is eight Allen-Bradley stations and four Siemens stations. These units can be stored on a shelf between labs.




From A-B, “The IP address of the Kinetix 350 drive is composed of four sub-octets that are separated by three dots to conform to the Class C Subnet structure. Each sub-octet can be configured with number between 1 and 254. As shipped from the factory, the default IP address of a drive is 192.168.124.200.”

The present IP address can be obtained from the drive’s display using the up-down keys and reading the address one sub-octet at a time.


A-B states that the drive can be assigned either using DHCP (dynamic IP address) or statically. The drive must be configured statically for our application. You must check that the IP address is already set or ping the address to check if it is operating. There should be an address label on the drive. If checking the drive, use the up-down arrow keys to locate the DHCP parameter and verify that it is set to 0. If not, set to 0 and cycle power.

When using the file given for the course, the controller is configured and ready to run except for the drive’s IP address. Configuration of the drive has been accomplished. The next few pages lead one through the process of defining the drive during the configuration process in preparation for the move command programming to follow.


If the controller is not configured, first follow the procedure below:




Notice that the controller must be at revision 20 or higher. Under the controller properties dialog box, click the Date/Time tab and enable Time Synchronization.




Configure the Kinetix 350 Drive. Right click to create a New Module. Clear the module type filters and check the Drive and Motion categories. Select the appropriate drive.




Configure the New Module using the following dialog box. The ethernet address must match the address set for the drive.




Under Change Module Definition, change the following:




Under the Associated Axes tab, click 'new axis' and add information:





Finish by checking 'create'. Next configure the Motion Group. In the Controller Organizer, right click Motion Groups and choose New Motion Group. Assign the axis just created to this motion group.






Right click on the axis in the Controller Organizer to change properties of the drive. For the motor:







To Configure the Motor

Use the scaling and loads appropriate for the application:







Actions and Parameters:









Download the application and test and tune the axes.







Auto-tune the Drive





Axis Properties for our application:





Motor Device Specification Properties





Motor Model Phase to Phase Properties





## Scaling Parameters





Test Polarity Screen



## Motor Load Characteristics





## Compliance Compensation





## Velocity Loop Properties









## Motion Planner




## Actions to Take Upon Conditions



### More Drive Parameters



Faults and Alarm Log Screen



Note:

Under Drive Parameters, Feedback1BatteryAbsolute, set to 'No' or 0. Otherwise, the hardware will generate a fault and you will not be able to run the axis.

Sample Commands for the A-B Application

Controller Organizer Scope: MainProgram Show: All Tags

Name	Value	Force Mask	Style	Data Type	Description
+ Action_000	{...}	{...}		SFC_ACTION	
+ Action_001	{...}	{...}		SFC_ACTION	
+ Cam	{...}	{...}		CAM	
+ Cam_Profile	{...}	{...}		CAM_PROFILE	
+ MCTags_1	{...}	{...}		MOTION_INSTR...	
+ MCTags_2	{...}	{...}		MOTION_INSTR...	
+ MCTags_3	{...}	{...}		MOTION_INSTR...	
+ MCTags_4	{...}	{...}		MOTION_INSTR...	
+ MI	2		Decimal	DINT	
+ Start	{...}	{...}		SFC_STEP	
+ Step_000	{...}	{...}		SFC_STEP	
+ Step_001	{...}	{...}		SFC_STEP	
+ Step_002	{...}	{...}		SFC_STEP	
+ Step_003	{...}	{...}		SFC_STEP	
+ Stop	{...}	{...}		SFC_STOP	
+ Time	{...}	{...}		TIMER	
Tran_000	0		Decimal	BOOL	
Tran_001	0		Decimal	BOOL	

## Setting Up a Sequence

Controller Organizer Scope: Motion\_AB Show: All Tags

Name	Value	Force Mask	Style	Data Type	Description
+ Axis2	{...}	{...}		AXIS_CIP_DRIVE	
+ Group	{...}	{...}		MOTION_GROUP	
+ K350_2:S	{...}	{...}		AB:Motion_Diagn...	
+ Step_Tag	2		Decimal	DINT	

Properties Panel for Step\_Tag:

- General**
  - Name: Axis2
  - Usage: <normal>
  - Type: Base
  - Alias For:
  - Base Tag:
  - Data Type: AXIS\_CIP\_DRIV
  - Scope: Motion\_AB
  - External Acce...: Read/Write
  - Style:
  - Constant: No
  - Required:
  - Visible:
- Description**
- Data**
  - Produced Connection
  - Consumed Connection


## More Examples of Sequences



## Kinetix 350 Drive Ethernet Port Configuration

The IP address of the Kinetix 350 drive is composed of four sub-octets that are separated by three dots to conform to the Class C Subnet structure. Each sub-octet can be configured with number between 1 and 254. As shipped from the factory the default IP address of a drive is 192.168.124.200.

There are two methods of changing the current IP address. An address can be assigned to the drive automatically (dynamic IP address) when the drive is connected to a DHCP (Dynamic Host Configuration Protocol) enabled server, or you can manually assign an IP address to the drive (static IP address). Both methods of configuring the drive's IP address are shown here.

### Obtain the Kinetix 350 Drives' Current Ethernet Settings

The current Ethernet setting and IP address of the Kinetix 350 drive can be obtained from the drive display and keypad. Press  on the display and use

  to access parameters IP\_1, IP\_2, IP\_3, and IP\_4. Each of these parameters contain one sub-octet of the full IP address, for example in the case of the drive default (factory set) address parameters:

IP\_1 = 192

IP\_2 = 168

IP\_3 = 124

IP\_4 = 200






By accessing these four parameters the full IP address on the drive can be obtained.

If parameters IP\_1, IP\_2, IP\_3, and IP\_4 all contain '----' rather than a numerical values it means that the drive has DHCP enabled and the DHCP server is yet to assign the drive its dynamic IP address. As soon as an IP address is assigned by the server the address assigned is displayed by the drive in the above parameters. See [Configure the IP Address Automatically \(dynamic address\) on page 83](#).

## Configure the IP Address Manually (static address)

When connecting directly from the Kinetix 350 drive to the personal computer without a server or when connecting to a private network, where all devices have static IP addresses, assign the IP address of the Kinetix 350 drive manually.


To assign the address manually, disable the DHCP mode. Do this by using the drive keypad and following these steps.


1. Press .
2. Use   to access parameter DHCP.
3. Check this parameter is set to a value of 0.
4. If the DHCP parameter is set to 1 then use  and  to set to 0.
5. Cycle power to the drive.

The change takes effect.

Do not forget step 5 – Cycle Power!







The following manual describes the setup of the drive:

[https://literature.rockwellautomation.com/idc/groups/literature/documents/um/2097-um002\\_-en-p.pdf](https://literature.rockwellautomation.com/idc/groups/literature/documents/um/2097-um002_-en-p.pdf)

Chapter 6 describes the Drive Safe Torque-off set-up. On pg. 107 the jumpers are shown that bypass the feature. In another chapter, the safety of a system is discussed. This chapter discusses the safe use of this drive and controller.



This work is licensed under a Creative Commons Attribution 4.0 International License.