# SIEMENS



# **Installing Software**

The software is called the TIA (Total Integrated Automation) Portal. The TIA Portal is really a combination of several industry leading titles. You might have received a collection of DVDs containing the software, or a link to Online Software Delivery (OSD). How ever you obtain the software you will need to install The STEP 7 Basic/Professional for Course2: Siemens Manufacturing and Automation. If you have received a disk set please check the version number on the disks. It will be in the form of SIMATIC STEP 7, S7-PLCSIM, STEP 7 Safety and WinCC V18. The version number follows the letter V and the license is tied to the version.

#### I want to:

Install software from a disk

Downloading installation files

**Downloading WinCC Panel Image files for HMI Communication** 

License the software

Download and install the automation license manager


Obtaining the on-line license

Setting up a license server

Obtaining help

#### Software from Disk

If your software came by DVD, you must save the Certificate of License that is attached to the DVD case. This certificate will allow Siemens to regenerate the license if for some reason the computer housing that license is no longer functioning.



Inside the DVD case are several sleeves of disks. You will need the one marked Simatic Step 7 Basic/Professional. Also in the disk set is a black thumb drive that houses the license. The license will be needed to utilize the software.




If you have a DVD drive and wish to install the software you will need to install disk one of the Simatic Step 7 Basic/Professional set. For most installations it is easier to have a digital version to work with.

## Downloading Installation files

If you need to download installation files for the installation those can be found on the Industry Online Support page. <a href="https://support.industry.siemens.com/cs/start?lc=en-US">https://support.industry.siemens.com/cs/start?lc=en-US</a>. If you do not have a login for the site, you will need to create one. Once logged in you can enter in the name of the software and version in the search box.



This will take you to a menu. Generally, you can download a trial version and it is found at the top of the list of links. This example is using the Version 18 (V18) of the software.




This example is using Version 18 and the link took us to <a href="https://support.industry.siemens.com/cs/document/109807109/simatic-step-7-incl-safety-s7-plcsim-and-wincc-v18-trial-download?dti=0&lc=en-AF">https://support.industry.siemens.com/cs/document/109807109/simatic-step-7-incl-safety-s7-plcsim-and-wincc-v18-trial-download?dti=0&lc=en-AF</a>

Once on the page, the upper part of the page are links to various ReadMe files about the software and licenses.


Scroll down the page until you come to DVD 1 Setup.



This is a disk image file for the necessary software to install. Click on the link. The download will begin and place the disk image file in your downloads. You can unpack the image using 7-zip (<a href="https://7-zip.org/">https://7-zip.org/</a>) Select Extract and it will pull the files out to a new folder for you.




The next window allows you to save the file to a desired location and provide a new name if desired.




Select OK and the 7-zip program will extract the files to the designated folder.

TIA\_Portal\_STEP7\_Prof\_Safety\_WINCC\_Adv\_Unified\_V18

Inside the folder you will find files for the installation and information about the software and licensing.



For information on other types of installations open the documents folder and look for the readme folder. Inside the readme folder is one marked English. Inside you will find various documents for items such as automated installation (PEAutoInstallenUS.pdf) and other topics.




For a single computer installation select the Start.exe file in the top level folder.. Restart the computer at the end of the installation.


## WinCC Panel Images

Course 3: Siemens Mechatronics and IoT will need the STEP 7 Basic and in addition will also need the installation files for WinCC Panel Images so the HMI panels will operate. You will find a link to the panel images from the original V18 download page. This example uses the V18 Version.

https://support.industry.siemens.com/cs/document/109807109/simatic-step-7-incl-safety-s7-plcsim-and-wincc-v18-trial-download?dti=0&lc=en-AF



Select the link to take you to the page, in this case it is <a href="https://support.industry.siemens.com/cs/document/109746530/image-downloads-for-hmi-operator-panels?dti=0&lc=en-AF">https://support.industry.siemens.com/cs/document/109746530/image-downloads-for-hmi-operator-panels?dti=0&lc=en-AF</a>. This page contains instructions for loading the software as well as the various images. Course 3, Mechatronics and IoT, uses the Basic Panel so select the link for that.



#### 1.3 Comfort / Mobile / Basic Panels

The image downloads for the SIMATIC HMI Comfort / Mobile / Basic Panels can be found under the following link:


> Image Downloads for SIMATIC HMI Operator Panels: Comfort / Mobile / Basic Panels

#### This will take you to yet another page

(https://support.industry.siemens.com/cs/document/109825897/image-downloads-for-simatic-hmi-operator-panels-unified-basic-panels?dti=0&lc=en-AF) . In this case there are two versions offered that will work with the V18 version of the software. There is a WinCC image setup that contains the image files for all the associated Operator Panels. The WinCC image setup contains a "Setup Wizard" that guides you through the installation and installs the image files into the appropriate place.

#### 

This process downloads an executable to the downloads folder.




When you double click on the file in the downloads folder it will perform the system user account control to allow it to install. Once you accept that you should see the welcome screen.




Select next. Select English as the language. Select Next.

Now you will be prompted where to extract the files to. Similar to the software install this defaults to the installers temp folder. This example uses


C:\Users\tomwh\AppData\Local\Temp\WinCC Unified Basic Panel V19.0. If you wish to take these files to another location in the future this is where you will find them.



Selecting next will begin the installation. If you have more than one installation on the computer it will prompt you for the version number. In this instance the Portal V18 is selected.



The installation will finish and the panel images will be ready for use.



Restart the computer.

# Licensing the Software

Once the software is installed it must be licensed for use. If you downloaded the trial version of the software it will have a 15-day license which you can replace with the license file sent with the software.

You can access the license manual from C:\Program Files\Siemens\Automation\Automation License Manager\manualalmapp\_b.pdf. The procedure for updating the license is found between pages 30-34

Downloading and installing the Automation Manager and On-Line Licenses If you received a note from the Siemens Online Software Delivery your license will be delivered on line. You will need to download the Automation License Manager. The link to download the license manager is

https://support.industry.siemens.com/cs/document/114358/handling-programs-for-authorization-or-licensing-of-simatic-products-(alm-authors)?dti=0&lc=en-WW Select the link for Siemens\_Automation\_License\_Manager

#### Installation


You can find more information in the ALM readme file: Proceed as follows for installation:

- 1. Close all programs before starting the setup.
- 2. Start the downloaded file "Siemens\_Automation\_License\_Manager\_V6.2 Upd1.exe" to unzip the installation files.
- 3. Then go to the directory with the unzipped files and start the file "Setup.exe" there.
- Now follow the instructions in the installation program.
- ☐ of Siemens\_Automation\_License\_Manager\_V6.2\_Upd1.exe (154.0 MB) (SHA-256)

SHA256: 8f432af0718a08e7b43318553dcb1de47a264a609bafb350e245db6ac7dfee9f

You will be prompted to login. If needed, you can create a new account by selecting the option first time here.


## SIEMENS




Once signed in you will be able to download the software. This software will be needed on every computer that will need to get a license as well as the computer you select as the license server if you wish to use one. The software is saved in the downloads folder and will have the current version as the name.




Double click on the executable and agree to let it make changes to the device in the user account control. This will bring up the installation setup for the Siemens Automation License Manager. Select Next.




In the dialog box you can extract to the default location and proceed to install on that computer. The file containing the extracted files can be copied to other computers if there is a desire to set up in multiple locations.






Once installed you might be asked to restart Windows.




After the restart you should be able to find the Automation License Manager listed in the Siemens Automation section of the all programs menu.


Obtaining the on-line license Open the Automation License Manager.



Start the automation license manager. When the license manager opens select the option of Online Software Delivery from one of the menus.




This should take you to the log in screen.




### Select Login.

Enter in your login name and password used earlier to download the license manager.




The page wants to affirm your account and wants to send a verification code to your email account. Select the send verification code button




Find the verification code in your email. Enter the verification code in the box and select verify input




Once verified you should see the indication that you have been accepted. Select Continue.



Check the boxes for the download location and export control. Then select continue.




The message will explain how to drag the license to the correct location.




Once you select close you should see the license in the window.


Drag the license from the transfer license(s) button to the drive you wish the license to appear. In this case we are moving it to the C: drive.



You will be warned that reversing the process is not possible.



You will see the transfer occur.




Once finished the licenses should appear on the drive you installed them to. Expand the folders all the way and you should see the licenses on that drive.




## Setting up a license server

The above process will license just the computer where the license exists. If you wish to access the license from another computer you need to adjust the settings on the license manager on both computers.


Go to the settings of the automation license manager in the file menu.




Once in the settings box place a check in the Forbid license keys transfer from local computer. This will allow others to use the license but prevents someone from the outside from taking the license.




Select the connection tab. On this tab you will be allowing remote connections and the port it will communicate on. In this example 4410 is used for communication. The box for allow remote connections is checked.




In the license manager of the computer you want to connect, begin at the edit menu and select connect computer.



In the connect computer dialog box, enter the name of the computer you want to connect t. Place a colon then the number 4410. You can enter in a display name or use the display name field.



On the computer that you want to access the license go to the settings from the license manager file menu. Select the favorites tab. You should see the name of the server computer and the port. Highlight the computer name and select the Add arrow to move the computer to the search list. Select OK.



The computer is now set to find a license from the server computer at the appropriate port.

## **Getting Help**

Support ticket request: <a href="http://www.usa.siemens.com/supportrequest">http://www.usa.siemens.com/supportrequest</a>

Once you log in you will be asked for the type of help you need and some basic information. They will assign a case ticket to it and get back to you with either a request for further information or an answer to the questions you have asked.

Industry Online Support page. <a href="https://support.industry.siemens.com/cs/start?lc=en-US">https://support.industry.siemens.com/cs/start?lc=en-US</a>.

This site provides access to downloads, blogs, questions and other information.

7-zip: <a href="https://7-zip.org">https://7-zip.org</a>

This site provides a free program for un-zipping files, combining RAR files and unpacking executables and disk image files